

## How to install HoldUp EVO 2"/SingleSpeed wedge alignment insert

1. Remove rack from hitch. Have a  $\frac{1}{4}$ " wrench or adjustable wrench available.



2. Remove acorn nut, washers, and wedge from long bolt.



3. Insert wedge alignment insert in the gap in the wedge and re-thread onto the bolt.



4. Re-attach acorn nut and tighten fully, do not need to re-install the washers.



5. Re-install rack into hitch.