BaseLine Pitch Adjustment

IMPORTANT! Make sure the arrow on the bottom center of the crossbar faces away from you

A

B

C