

ROCKETBOX PRO MEASUREMENTS 2012

Box	Length (in)	Width (in)	Height (in)	Capacity (ft^3)	Internal Length (lid support to lid support) (in)	Internal width (between the latches) (in)	Crossbar Spread minimum (in)	Crossbar Spread maximum (in)	Front Overhang Minimum (front lip to Xbar center) (in)	Front Overhang Maximum (front lip to Xbar center) (in)	Rear Overhang Minimum (rear lip to Xbar center) (in)	Rear Overhang Maximum (rear lip to Xbar center) (in)
RocketBox Pro 11	89	24	16	11.0	77.0	14.0	24	40	38	46	12.5	19
RocketBox Pro 12	58	36	16	12.0	48.0	26.5	24	32	14	18	11	16
RocketBox Pro 14	74	33	16	14.0	64.0	23.5	24	40	22	29.5	12	20

SKYBOX MEASUREMENTS 2012

Box	Length (in)	Width (in)	Height (in)	Capacity (ft^3)	Internal Length (lid support to lid support) (in)	Internal width (between the latches) Min/Max (in)	Crossbar Spread minimum (in)	Crossbar Spread maximum (in)	Front Overhang Minimum (front lip to Xbar center) (in)	Front Overhang Maximum (front lip to Xbar center) (in)	Rear Overhang Minimum (rear lip to Xbar center) (in)	Rear Overhang Maximum (rear lip to Xbar center) (in)
SKYBOX 12	92	24	16	12.0	80.0	15.25/18.5	24	42	25	33	24	32
SKYBOX 16	81	36	15	16.0	70.0	24.5/29	24	36	21	27	22	28
SKYBOX18	92	36	16	18.0	80.0	24.5/29	24	42	25	33	24	32
SKYBOX21	92	36	18	21.0	80.0	24.5/29	24	42	25	33	24	32
SKYBOX LOPRO	92	36	11	15.0	80.0	24.5/29	24	42	25	33	24	32

ShowCase Measurements 2016

Box	Length (in)	Width (in)	Height (in)	Capacity (ft^3)	Internal Length (lid support to lid support) (in)	Internal width (between the latches) Min/Max (in)	Crossbar Spread minimum (in)	Crossbar Spread maximum (in)	Front Overhang Minimum (front lip to Xbar center) (in)	Front Overhang Maximum (front lip to Xbar center) (in)	Rear Overhang Minimum (rear lip to Xbar center) (in)	Rear Overhang Maximum (rear lip to Xbar center) (in)	Max lid opening
SHOWCASE 15	80	37	14.5	15.0	68.0	26/28.5	24	34	27	34	19	21	13
SHOWCASE 20	91	37	17	20.0	78.0	26/28.5	24	40	27	34	23	23	11.25

RocketBox Pro METRIC

Box	Length (cm)	Width (cm)	Height (cm)	Capacity (m^3)	Internal Length (lid support to lid support) (cm)	Internal width (between the latches) (cm)	Crossbar Spread minimum (cm)	Crossbar Spread maximum (cm)	Front Overhang Minimum (front lip to Xbar center) (cm)	Front Overhang Maximum (front lip to Xbar center) (cm)	Rear Overhang Minimum (rear lip to Xbar center) (cm)	Rear Overhang Maximum (rear lip to Xbar center) (cm)
RocketBox Pro 11	226	61	41	0.31	195.00	35.00	61	102	97	117	32	48
RocketBox Pro 12	147	91	41	0.34	121.00	67.00	61	81	36	46	28	41
RocketBox Pro 14	188	84	41	0.39	162.00	59.00	61	102	56	75	30	51

SKYBOX METRIC

Box	Length (cm)	Width (cm)	Height (cm)	Capacity (m^3)	Internal Length (lid support to lid support) (cm)	Internal width (between the latches) Min/Max (cm)	Crossbar Spread minimum (cm)	Crossbar Spread maximum (cm)	Front Overhang Minimum (front lip to Xbar center) (cm)	Front Overhang Maximum (front lip to Xbar center) (cm)	Rear Overhang Minimum (rear lip to Xbar center) (cm)	Rear Overhang Maximum (rear lip to Xbar center) (cm)
SKYBOX 12	234	61	41	0.34	203.0	39 /47	61	107	64	33	84	56
SKYBOX 16	206	91	38	0.45	178.0	62 /74	61	91	53	27	56	71
SKYBOX18	234	91	41	0.51	203.0	62 /74	61	107	64	33	84	56
SKYBOX21	234	91	46	0.59	203.0	62 /74	61	107	64	33	84	56
SKYBOX LOPRO	234	91	28	0.42	203.0	62 /74	61	107	64	33	84	56

ShowCase Metric Measurements 2016

Box	Length (cm)	Width (cm)	Height (cm)	Capacity (m^3)	Internal Length (lid support to lid support) (cm)	Internal width (between the latches) Min/Max (cm)	Crossbar Spread minimum (cm)	Crossbar Spread maximum (cm)	Front Overhang Minimum (front lip to Xbar center) (cm)	Front Overhang Maximum (front lip to Xbar center) (cm)	Rear Overhang Minimum (rear lip to Xbar center) (cm)	Rear Overhang Maximum (rear lip to Xbar center) (cm)	Max lid opening (cm)
SHOWCASE 15	203	94	37	0.4	173.0	66/72	61	86	69	86	48	53	33
SHOWCASE 20	231	94	43	0.6	198.0	66/72	61	102	69	86	58	58	28.5